



Figure 12.

Using the Fixture

The amount of offset is controlled from the front face by loosening the two flat head screws and rotating the inset circle using the pendant mount as a handle. The rotation of the pendant mount is done by removing the inset circle and loosening the 1" flat head screw from the back.

The finished pendant should have a diameter larger than the diameter of the pendant mount (2" in the instructions) and the pendant mount at least $\frac{1}{4}$ " proud of the inset circle surface. That way you can turn and finish the edges and front face without removing the pendant from the mount. If you like smaller pendants make a smaller diameter pendant mount.

Normally, I mount a flattened and finished back of a pendant blank to the centered pendant mount with double sided tape and turn the front face and edges. You can then set the offset and rotation to decorate the face as desired. Sand and finish and you're done.